

Marca	Modelo	Serie	Desde Hasta	Aire	Habitaculo	Aceite	Combustible
MAZDA	121	121 LX	0000-00-00 - en adelante			OL476	
MAZDA	2200	2200	0000-00-00 - en adelante -		-	OL365	-
MAZDA	2500	B 2500 Diesel 2,5	0000-00-00 - en adelante -		-	-	GS139
MAZDA	2600	B 2600	0000-00-00 - en adelante -		-	OL477	-
MAZDA	3000	E 3000	0000-00-00 - en adelante -		-	-	GS014
MAZDA	323	323 1.6i, 1.9i V16	1989-10-01 - en adelante	AR346	-	-	-
MAZDA	323	323 2.0 Tdi	1999-01-01 - en adelante -		-	-	GS103
MAZDA	323	323 F, GLX, GL	2000-03-31 - en adelante -		-	OL476	-
MAZDA	626	626 2.0 TD	2000-03-31 - en adelante -		-	-	GS103
MAZDA	626	626 II 2.0 FE	1986-05-01 - 1987-12-01 -		-	OL524	-
MAZDA	626	626 III 2.5 V6 KL	1987-05-01 - 1992-12-01 -		-	OL524	-
MAZDA	626	626 IV 1.6 GLX	1992-12-01 - en adelante -		-	OL524	-
MAZDA	626	626 V 2.0	0000-00-00 - en adelante -		-	OL502	-
MAZDA	929	929 1.8 - 2.0	0000-00-00 - en adelante -		-	OL198	TN3
MAZDA	929	929 FE 2.0	1987-06-01 - 1991-06-01 -		-	OL198	-
MAZDA	929	929 FE 2.2	1988-01-01 - en adelante -		-	OL198	-
MAZDA	929	929 F2E 2.2i	1987-05-01 - 1988-12-01 -		-	OL198	-
MAZDA	929	929 Sedan	0000-00-00 - en adelante -		-	OL476	-
MAZDA	Furgon - Pick Up	Furgon - Pick Up	0000-00-00 - en adelante -		-	OL526	-
MAZDA	MPV	MPV	0000-00-00 - en adelante -		-	OL476	-
MAZDA	MX 5	MX 5 1.8	1993-08-01 - 1994-11-01	AR346	-	-	-
MAZDA	MX 5	MX 5 Miata	0000-00-00 - en adelante -		-	OL476	-
MAZDA	MX 6	MX 6 KL2.5 V6	1994-04-01 - en adelante -		-	OL198	-
MAZDA	MX 6	MX 6 2.0 FS	1992-01-01 - en adelante -		-	OL524	-
MAZDA	MX 6	MX 6 2.5 V6 KL	1992-01-01 - en adelante -		-	OL524	-
MAZDA	MX3	MX 3	0000-00-00 - en adelante -		-	OL476	-
MAZDA	MX3	MX 3 1,8 S	1992-01-01 - 1994-01-01	AR1634PM	-	-	-
MAZDA	Pick Up	Pick- Up	0000-00-00 - en adelante -		-	OL476	-